



UNIVERSAL TABLET MOUNTING STATION

INSTALLATION INSTRUCTIONS

450-4119



Loosen locknuts on back of Mounting Station.




Place your tablet into Mounting Station



Lock your mounting station.



Flip mounting station over onto face.



Move all adjustments on Mounting Station to make a snug fit onto tablet.



Tighten all locknuts.

***DESIGNED TO FIT MULTIPLE TABLETS
WHEN USED WITH AN OTTER BOX®
or SIMILAR CASE.***

Adjustable to fit tablets from 7.18 – 8.3" height x 9.84 – 12.5" width and 0.84" deep

** We recommend use of a protective case to further secure tablet and prevent vibration against metal parts.*

If you have questions or need further assistance please call Technical Support: 1.877.455.6886

405 W. EASY ST., ROGERS, AR 72756 • TENHOLD.COM • 12/25

Tenhold™, a division of Kiefer Sage™. Specifications subject to change without notice.

SKU 050-0256-00